
–weishaupt–

manual

Installation and operating instruction



Gas burner WG20…/1-C Z-LN

83054602 ▪ 1/2020-01

1 User instructions 5
1.1 Target group 5
1.2 Symbols 5
1.3 Guarantee and Liability 6

2 Safety 7
2.1 Designated application 7
2.2 When gas can be smelled 7
2.3 Safety measures 7
2.3.1 Personal protective equipment (PPE) 7
2.3.2 Normal operation 7
2.3.3 Electrical work 8
2.3.4 Gas supply 8
2.4 Alterations to the construction of the equipment 8
2.5 Noise emission 8
2.6 Disposal 8

3 Product description 9
3.1 Type key 9
3.2 Serial number 10
3.3 Function 11
3.3.1 Air supply 11
3.3.2 Gas supply 12
3.3.3 Electrical components 13
3.3.4 Program sequence 14
3.4 Technical data 16
3.4.1 Approval data 16
3.4.2 Electrical data 16
3.4.3 Ambient conditions 16
3.4.4 Fuels 16
3.4.5 Emissions 17
3.4.6 Rating 18
3.4.7 Dimensions 19
3.4.8 Weight 20

4 Installation 21
4.1 Installation conditions 21
4.2 Burner installation 22
4.2.1 Rotate burner by 180° (optional) 23

5 Installation 25
5.1 Gas supply 25
5.1.1 Installing the gas valve train 26
5.1.2 Carry out soundness test of gas supply line and vent 28
5.2 Electrical connection 29

6 Operation 30
6.1 Operating panel 30
6.2 Display 30

7 Commissioning 31
7.1 Prerequisite 31
7.1.1 Connect measuring devices 32
7.1.2 Check gas connection pressure 33
7.1.3 Check soundness of gas valve train 34
7.1.4 Purging the gas valve train 37
7.1.5 Preset pressure regulator 38
7.1.6 Setting values 40
7.1.7 Preset gas and air pressure switch 41
7.2 Adjusting the burner 42
7.3 Set pressure switches 46
7.3.1 Set gas pressure switch 46
7.3.2 Set air pressure switch 47
7.4 Concluding work 48
7.5 Check combustion 49
7.6 Calculate gas throughput 50

8 Shutdown 51

9 Servicing 52
9.1 Notes on servicing 52
9.2 Service plan 54
9.3 Removing and refitting mixing head 55
9.4 Set mixing head 56
9.5 Set ionisation and ignition electrodes 57
9.6 Service position 58
9.7 Removing and refitting fan wheel 58
9.8 Remove burner motor 59
9.9 Removing and refitting air damper actuator 60
9.10 Removing and refitting angle drive 61
9.11 Removing and refitting gas butterfly valve 62
9.12 Removing and refitting air regulator 63
9.13 Replacing coil on multifunction assembly 64
9.14 Replace breather plug of multifunction assembly 65
9.15 Removing and refitting filter insert of multifunction assembly 66
9.16 Replacing the fuse 67

10 Troubleshooting 68
10.1 Procedures for fault conditions 68
10.1.1 Illuminated push button off 68
10.1.2 Illuminated push button red 69
10.1.3 Illuminated push button flashes 73
10.2 Operating problems 73

11 Technical documentation 74
11.1 Wiring diagram 74
11.2 Conversion table unit of pressure 76
11.3 Appliance categories 77

12 Project planning 81
12.1 Continuous running fan or post-purge 81

13 Spares 82

14 Notes 92

15 Key word index 93

1 User instructions

Translation of original operating instructions

This manual forms part of the equipment and must be kept on site.

Carefully read the manual prior to working on the unit.

1.1 Target group

The manual is intended for the operator and qualified personnel. It should be observed by all personnel working with the unit.

Work on the unit must only be carried out by personnel who have the relevant training and instruction.

Persons with limited physical, sensory or mental capabilities may only work on the unit if they are supervised or have been trained by an authorised person.

Children must not play with the unit.

1.2 Symbols

 DANGER	Immediate danger with high risk. Non observance can lead to serious injury or death.
 WARNING	Danger with medium risk. Non observance can lead to environmental damage, serious injury or death.
 CAUTION	Danger with low risk. Non observance can cause damage to the equipment and injury to personnel.
	Important information
▸	Requires direct action
✓	Result after an action
▪	Itemisation
…	Range of values

1.3 Guarantee and Liability

Guarantee and liability claims for personal and equipment damage are excluded, if they can be attributed to one or more of the following causes:

- non approved application,
- non-observance of the manual,
- operation with faulty safety equipment,
- continual operation despite a fault,
- improper installation, commissioning, operation and service,
- repairs, which have been carried out incorrectly,
- the use of non original Weishaupt parts,
- force majeure,
- unauthorised modifications made to the unit,
- the installation of additional components, which have not been tested with the unit,
- the installation of combustion chamber inserts, which impede full flame formation,
- unsuitable fuels,
- defects in the inlet lines.

2 Safety

2.1 Designated application

The burner is suitable for operation on heat exchangers to EN 303 and EN 676.

If the burner is not used on combustion chambers to EN 303 and EN 676, a safety assessment of combustion and flame stability during individual process conditions and of the shutdown limits of the combustion plant has to be carried out and documented.

The combustion air must be free from aggressive compounds (e.g. Halogens). If the combustion air in the boiler room is contaminated, increased cleaning and servicing will be required. In this case ducted air intake is recommended.

The burner should only be used in enclosed rooms.

Improper use could:
- endanger the health and safety of the user or third parties,
- cause damage to the unit or other material assets.

2.2 When gas can be smelled

Avoid open flames and spark generation, for example:
- do not operate light switches,
- do not operate electronic equipment,
- do not use mobile telephones.

- ► Open doors and windows.
- ► Close gas isolating valve.
- ► Warn the inhabitants, do not ring door bells.
- ► Leave the building.
- ► Inform the heating contractor or gas supplier from outside of the building.

2.3 Safety measures

Safety relevant fault conditions must be eliminated immediately.

Components, which show increased wear and tear or whose design lifespan is or will be exceeded prior to the next service should be replaced as a precaution.

The design lifespan of the components is listed in the service plan [ch. 9.2].

2.3.1 Personal protective equipment (PPE)

Use the necessary personal protective equipment for all work.

2.3.2 Normal operation

- All labels on the unit must be kept in a legible condition.
- Stipulated settings, service and inspection work should be carried out at regular intervals.
- Only operate the unit with its cover closed.

2.3.3 Electrical work

For work carried out on live components:
- Observe the accident prevention instructions DGUV Regulation 3 and adhere to local directives,
- tools in accordance with EN 60900 should be used.

The device contains components, which could be damaged by electrostatic discharge (ESD).
When working on circuit boards and contacts:
- do not touch circuit boards or contacts,
- if necessary, take ESD protective measures.

2.3.4 Gas supply

- Only the gas supply company or an approved agent may carry out installation, alteration and maintenance work on gas appliances in buildings and properties.
- Pipework must be subject to a combined load and valve proving test and/or usability testing relative to the pressure range intended, e. g. DVGW-TRGI, worksheet G 600.
- Inform the gas supply company about the type and size of plant prior to installation.
- Local regulations and guidelines must be observed during installation, e. g. DVGW-TRGI, worksheet G 600; TRF Band 1 and Band 2.
- The gas supply pipework should be suitable for the type and quality of gas and should be designed in such a way that it is not possible for liquids to form, e. g. condensate. Observe vaporisation pressure and vaporisation temperature of liquid petroleum gas.
- Use only tested and approved sealing materials, whilst observing all process information.
- Re-commission the appliance when changing to a different type of gas. Changing from LPG to Natural Gas and visa versa requires a conversion.
- Carry out soundness test after each service and fault rectification.

2.4 Alterations to the construction of the equipment

All conversions require written approval from Max Weishaupt GmbH.

- No additional components may be fitted, which have not been tested for use with the equipment.
- Do not use combustion chamber inserts, which hinder flame burnout.
- Use only original Weishaupt replacement parts.

2.5 Noise emission

The noise emissions are determined by the acoustic behaviour of all components fitted to the combustion system.

Prolonged exposure to high noise levels can lead to loss of hearing. Provide operating personnel with protective equipment.

Noise emissions can further be reduced with a sound attenuator.

2.6 Disposal

Dispose of all materials and components in a safe and environmentally friendly way at an authorised location. Observe local regulations.

3 Product description


3.1 Type key

Example: WG20N/1-C Z-LN

Type	
W	Series: Compact burner
G	Fuel: Gas
20	Size
N	N: Natural Gas F: Liquid Petroleum Gas
1	Ratings size
C	Construction
Version	
Z	Type of control: two stage
LN	Mixing head: LowNO_x

3.2 Serial number

The serial number on the name plate identifies the product. This is required by Weishaupt's customer service department.



① Name plate

Ser.No. _____

3.3 Function

3.3.1 Air supply

Air damper

The air damper regulates the air quantity required for combustion. The combustion manager drives the air damper via actuator.

At burner shutdown the the actuator automatically closes the air damper. At burner shutdown the air dampers close automatically.

Fan wheel

The fan wheel supplies the air from the air intake housing to the combustion head.

Diffuser

The air gap between flame tube and diffuser is adjusted by positioning the diffuser. This adjusts the mixing pressure and the air quantity required for combustion.

Air pressure switch

The air pressure switch monitors the fan pressure. If the fan pressure is insufficient, the combustion manager initiates a lockout.

3.3.2 Gas supply

Gas isolating valve ①

The gas isolating valve opens and shuts off the gas supply.

Multifunction assembly ⑧

The multifunction assembly contains:

Gas filter ②	The gas filter protects the subsequent valve train components from foreign particles.
Double gas valve ④	The double gas valve opens and shuts off the gas supply.
Pressure regulator ③	The pressure regulator reduces the connection pressure and ensures a constant setting pressure.

Gas butterfly valve ⑤

The gas butterfly valve regulates the gas quantity depending on the rating required. The air/gas ratio is adapted via mechanical compound to the air damper setting.

Low gas pressure switch/ valve proving gas pressure switch ⑦

The gas pressure switch monitors the gas connection pressure. If the preset pressure is not achieved, the combustion manager initiates a safety shutdown.

The gas pressure switch also monitors if the gas valves are tight. It signals the combustion manager if the pressure increases or decreases to an impermissible level during valve proving.

Valve proving is carried out automatically by the combustion manager:
- after every controlled shutdown,
- prior to burner start following lockout or power outage.

1. Test phase (function sequence for valve proving valve 1):
- Valve 1 closes,
- valve 2 closes after a delay,
- the gas escapes and the pressure between valve 1 and valve 2 reduces,
- both valves remain closed for 8 seconds.


If the pressure increases to above the value set during these 8 seconds, valve 1 is leaking. The combustion manager initiates a controlled shutdown.

2. Test phase (function sequence for valve proving valve 2):
- Valve 1 opens, valve 2 remains closed,
- pressure between valve 1 and valve 2 increases,
- valve 1 closes again,
- both valves remain closed for 16 seconds.

If the pressure decreases to below the value set during these 16 seconds, valve 2 is leaking. The combustion manager initiates a controlled shutdown.

High gas pressure switch ⑥ (optional)

The high gas pressure switch monitors the setting pressure. If the setting pressure exceeds the value set, the combustion manager initiates a controlled shutdown.



3.3.3 Electrical components

Combustion Manager

The combustion manager W-FM is the control unit of the burner.

It controls the sequence of operation and monitors the flame.

Burner motor

The burner motor drives the fan wheel.

Ignition unit

The electronic ignition unit creates a spark at the electrode, which ignites the fuel/air mixture.

Ionisation electrode

The combustion manager monitors the flame signal via the ionisation electrode.

If the flame signal becomes too weak, the combustion manager carries out a controlled shutdown.

3.3.4 Program sequence

Pre-purge

At heat demand, the actuator drives to full load position after the initialisation time (T_I) has elapsed.
The burner motor starts and the air pressure switch reacts.
The combustion chamber is pre-purged.

Ignition

Following the pre-purge phase (T_V) the actuator drives to ignition position.
Ignition starts.

Fuel release

Following pre-ignition time (T_{VZ}) valve 1 opens and the gas pressure switch reacts.
Valve 2 opens and releases the fuel.

Safety time

With fuel release, safety time (T_S) and post-ignition time (T_{NZ}) start.

The flame signal must be present within the safety time (T_S).

Operation


The ionisation electrode monitors the flame.
The air damper actuator opens and closes depending on the regulator demand for full load.
The residence time partial load (T_{VK}) prevents cycling between partial and full load.

Post-purge

If there is no longer a heat demand, the solenoid valves close and stop the fuel supply.
Post-purge time (T_N) and valve proving begins [ch. 3.3.2].

Following the post-purge time (T_N) the burner motor switches off.

The air damper actuator drives to the Closed position.



B1	Ionisation electrode	T_I	Initialisation time (Test): 3 s
B10	Air pressure switch	T_N	Post-purge time: 1.2 s
B15	Temperature or pressure regulator	T_{NZ}	Post-purge time: 2.5 s
B16	Temperature or pressure regulator full load	T_{P1}	First test phase: 9.3 s (valve proving valve 1)
B31	Low gas pressure switch	T_{P2}	2nd test phase: 9.7 s (valve proving valve 2)
F2	Temperature or pressure limiter	T_S	Safety time: 2.8 s
K32	double gas valve	T_V	Pre-purge time: 21.5 s
K33	External valve LPG	T_{VK}	Residence time partial load: 5 s
M1	Burner motor	T_{VZ}	Pre-ignition time: 2 s
M20	Air damper actuator		Voltage is applied
P6	Control lamp operation (optional)		Flame signal present
P11	Control lamp full load (optional)		Current path
T1	Ignition unit		Start (orange)
①	CLOSED position (ST0)		Ignition phase (flashing orange)
②	Ignition load (ZL Gas)		Burner operation (green)
③	Partial load (ST1)		
④	Full load (ST2)		

3.4 Technical data

3.4.1 Approval data

PIN (EU) 2016/426	CE-0085BM0216
Basic standards	EN 676:2008 Additional standards, see EU conformity certification.

3.4.2 Electrical data

Mains voltage / mains frequency	230 V/50 Hz
Consumption at start	max 466 W
Consumption during operation	max 366 W
Power consumption	max 2.3 A
Internal unit fuse	T6.3H, IEC 127-2/5
External fuse	max 16 AB

3.4.3 Ambient conditions

Temperature in operation	–15 … +40 °C
Temperature during transport / storage	–20 … +70 °C
relative humidity	max 80 %, no dew point
Installation elevation	max 2000 m(1

(1 Consultation with Weishaupt is required for higher installation elevation.

3.4.4 Fuels

- Natural Gas E/LL
- Liquid Petroleum Gas B/P

3.4.5 Emissions

Flue gas

To EN 676 the burner complies with emission class 3.

The NO_x values are influenced by:
- combustion chamber dimensions
- flue gas system
- fuel
- combustion air (temperature and humidity)
- medium temperature

Combustion chamber dimensions, see Weishaupt Partner Portal / Documents and Applications / Online Applications / NO_x calculation for burners.

Sound levels

Dual number noise emission values	
Measured sound power level L_{WA} (re 1 pW)	75 dB(A)(1
Uncertainty value K_{WA}	4 dB(A)
Measured sound pressure level L_{pA} (re 20 µPa)	71 dB(A)(2
Uncertainty value K_{pA}	4 dB(A)

(1 Determined to ISO 9614-2.
(2 Determined at 1 metre distance from the front of the burner.
The measured noise levels plus uncertainty values form the upper limit value, which could occur when measuring.

3.4.6 Rating

Combustion heat rating


Natural Gas Liquid Petroleum Gas	35 … 200 kW 35 … 200 kW
Combustion head	WG20-C

Capacity graph

Capacity graph to EN 676.

The capacity data given relates to an installation elevation of 0 m above sea level. For installation elevations above 0 m a capacity reduction of approx. 1 % per 100 m applies.


A limited capacity graph is valid for ducted air intake.



① Combustion heat rating [kW]
② Combustion chamber pressure [mbar]


3.4.7 Dimensions

Burner



① 140 mm without combustion head extension
240 mm with combustion head extension (100 mm)
340 mm with combustion head extension (200 mm)
440 mm with combustion head extension (300 mm)

Gas valve train



	Gas valve train	Isolating valve	With thermal shut off device	Without thermal shut off device
①	W-MF 507	Rp¾	approx. 315 mm	approx. 300 mm
		Rp1	approx. 320 mm	approx. 305 mm
	W-MF 512	Rp1	approx. 350 mm	approx. 330 mm
②	W-MF 507	Rp¾	approx. 305 mm	approx. 290 mm
		Rp1	approx. 315 mm	approx. 295 mm
	W-MF 512	Rp1	approx. 355 mm	approx. 335 mm

3.4.8 Weight

approx. 20 kg

4 Installation

4.1 Installation conditions

Burner type and capacity graph

Burner and heat exchanger must be matched.

► Check burner type and burner capacity.

Installation location

► Prior to installation ensure that:
- sufficient space is available for normal and service position [ch. 3.4.7],
- sufficient combustion air is available, if necessary install ducted air intake,


Prepare heat exchanger

The refractory ③ must not protrude beyond the front edge of the combustion head. The refractory can take a conical shape (min 60°).

Refractory may not be required on boilers with water-cooled front, unless the manufacturer gives other instructions.

Following installation, the aperture ④ between flame tube and refractory should be filled with flame-proof, resilient insulating material. Do not make solid.

Heat exchangers with deep refractories or thick doors, or heat exchangers with reverse flame combustion chambers may require a combustion head extension. Head extensions of 100, 200 and 300 mm are available. Dimension ② then changes according to the head extension used.




① Flange gasket
② 140 mm
③ Refractory
④ Aperture

4.2 Burner installation


Only valid in Switzerland
When installing and operating the regulations of SVGW, VKF, local and Cantonal regulations and the EKAS guideline (LPG Guideline Part 2) must be observed.

The burner in its standard version is designed for valve train connection from the right. For gas valve train connection from the left the burner has to be installed rotated by 180°. This requires conversion measures [ch. 5.1.1].

- ► Remove mixing head [ch. 9.3].
- ► Remove burner flange ① from burner housing.
- ► Fit flange gasket ② and burner flange ① to the heat exchanger using screws ③.
- ► The aperture between combustion head and refractory should be filled with flame-proof, resilient insulating material (do not make solid).



- ► Mount burner with screws ① to burner flange.




- ► Check setting of electrodes [ch. 9.5].
- ► Fit mixing head [ch. 9.3].


4.2.1 Rotate burner by 180° (optional)

The following are required for the conversion:
- actuator adapter with fixing screws,
- lever with a longer shaft.

- ► Remove actuator ①.
- ► Disconnect linkage ③.
- ► Remove complete lever ②.
- ► Fit lever with longer shaft ④ to angle drive.
- ► Fit adapter ⑤.
- ► Turn indicator ⑥ to CLOSED position and hold.
- ► Mount actuator rotated by 180° whilst sliding the shaft ④ into the star shaped groove ⑦.



- ▶ Rotate burner flange ① 180° and mount with flange gasket.
- ▶ Rotate burner 180° and fit screws ② to burner flange.
- ▶ The aperture between combustion head and refractory should be filled with flame-proof, resilient insulating material (do not make solid).



- ▶ Check setting of electrodes [ch. 9.5].
- ▶ Fit mixing head [ch. 9.3].

5 Installation

5.1 Gas supply



DANGER

Risk of explosion due to leaking gas
Gas leaks can lead to a build-up of explosive gas/air mixture. With an ignition source present this can result in an explosion.
- ► Install gas supply with care.
- ► Observe all safety instructions.

Only an approved gas installer may carry out the gas side connection. Observe local regulations.

The following should be obtained from the gas supply company:
- Type of gas
- Gas connection pressure.
- Maximum CO_2 content in the flue gas.
- Calorific value in normal condition [kWh/m^3].

Observe maximum permissible pressure of all components of the gas valve train.


- ► Close all fuel shut off devices prior to commencing work and protect from accidental re-opening.

General installation instructions

- Install manually operated shut off device (gas isolating valve) in the supply.
- Ensure correct mounting alignment and cleanliness of sealing surfaces.
- Mount valve train free of vibration. It must not be allowed to swing. Suitable supports should be fitted.
- Mount gas valve train free of stresses.
- The distance between burner and multifunction assembly should be as small as possible. If the distance is too great, it is possible that a gas/air mixture is formed, which will influence burner start.
- Observe sequence and flow direction of gas valve train.
- If necessary, fit thermal shut off device (TAE) in front of the gas isolating valve.

Installation position

Multifunction assembly can be installed with the axis standing vertical to lying horizontal.




5.1.1 Installing the gas valve train

Only in conjunction with W-MF and gas connection pressure > 150 mbar
If the gas connection pressure is > 150 mbar, a pressure regulator has to be fitted upstream of the W-MF.
► Install the gas valve train, see additional sheet (Print No. 835109xx).

Installing the valve train from the right

► Remove protective foil from gas connection flange.
► Mount gas valve train free from stresses. Do not compensate for installation errors by over-tightening the flange screws.
► Ensure correct alignment of flange seals.
► Tighten screws evenly diagonally across.


No additional sealant is required if the thread is coated in blue.



Installing the gas valve train from the left


To fit the gas valve train to the burner from the left, the burner has to be installed rotated by 180°. To do this, additional conversion measures are required.

Move the gas pressure switch prior to installing the multifunction assembly:
- ► Remove closing plug ① and gas pressure switch ③.
- ► Mount gas pressure switch ③ and O ring ② on the opposite side.
- ► Mount closing plug ① on the opposite side.



- ► Continue installation in the same way as for "Mount gas valve train from the right".

Accessories



① Low gas pressure switch with mechanical interlock (B34)
② High gas pressure switch (B33)

5.1.2 Carry out soundness test of gas supply line and vent

Only the gas supply company or a contract installation company may carry out a soundness test and vent the gas line.

5.2 Electrical connection

DANGER


Risk of electric shock
Working on the device when voltage is applied can lead to electric shock.
- ► Isolate the device from the power supply prior to starting any work.
- ► Safeguard against accidental restart.

The electrical connection must only be carried out by qualified electricians. Observe local regulations.

For single stage operation, a bridge has to be connected in the connection plug ④ supplied as per wiring diagram.

Observe wiring diagram [ch. 11.1].

- ► Plug in plug for gas pressure switch ② and double gas valve ③ and secure with screws.
- ► Check polarity and wiring of 7 pole connection plug ①.
- ► Plug in connection plug ①.
- ► Check polarity and wiring of 4 pole connection plug ④.
- ► Plug in connection plug ④.



With remote reset, install connection line separately. Do not exceed maximum cable length of 10 metres.


6 Operation

6.1 Operating panel

CAUTION

Damage to the combustion manager due to incorrect operation
Excessive pressure applied to the illuminated push button can damage the combustion manager.
► Only lightly press illuminated push button.

The illuminated push button on the combustion manager has the following functions:
- display operating condition [ch. 6.2],
- display fault codes [ch. 10.1.2],
- reset burner lockout [ch. 10.1.2].



Re-starting the burner during burner operation:
► Press illuminated push button for 1 second.

6.2 Display

Illuminated push button	Operating condition
orange	Start phase
Flashing orange	Ignition and pre-purge phase
Green	Operation
red	Fault [ch. 10]

Additional flashing signals can be read off as fault code [ch. 10].

7 Commissioning

7.1 Prerequisite

Commissioning must only be carried out by qualified personnel.

Only correctly carried out commissioning ensures the operational safety.



Do not operate the burner outside of the capacity graph [ch. 3.4.6].

► Prior to commissioning ensure that:
- all assembly and installation work has been carried out correctly,
- sufficient combustion air is available, if necessary install ducted air intake
- the annulus between flame tube and heat exchanger is filled
- the heat exchanger is filled with medium
- the regulating, control and safety devices are functioning and set correctly
- the flue gas ducts are unimpeded
- a measuring point conforming to standards is available to measure the flue gas
- the heat exchanger and flue gas ducting up to the test point are sound (extraneous air influences the test results)
- the operating instructions of the heat exchanger are complied with
- a heat demand is available

Additional system-related tests could be necessary. Please observe the operating guidelines for the individual components.

On installations with process equipment, the conditions for safe operation and commissioning must be met, see worksheet 8-1 (Print No. 831880xx).


7.1.1 Connect measuring devices

Measuring device for ionisation current

- ▶ Remove ionisation cable from the plug coupling.
- ▶ Connect current measuring device in series.


Ionisation current

Extraneous light detection from	0.8 µA
Minimum ionisation current	1.5 µA
Recommended ionisation current	5 … 20 µA



Pressure measuring device for mixing pressure

- ▶ Open pressure test point for mixing pressure ① and connect pressure measuring device.



7.1.2 Check gas connection pressure

Minimum connection pressure

Add the combustion chamber pressure in mbar to the minimum connection pressure. The connection pressure should not fall below 15 mbar.

► Determine minimum connection pressure for low pressure installations from table [ch. 7.1.5].

Maximum connection pressure

Maximum connection pressure into isolating valve is 300 mbar.

Check connection pressure

DANGER


Risk of explosion due to excess gas supply pressure
Exceeding the maximum connection pressure (see name plate) can damage the gas valve train and lead to an explosion.
Max. connection pressure see name plate.
► Check gas connection pressure

Only in conjunction with W-MF and gas connection pressure > 150 mbar
The pressure measuring device must be connected to the pressure regulator.
► Check gas connection pressure, see additional sheet (print No. 835109xx).

► Connect pressure measuring device to test point ①.
► Slowly open isolating valve whilst observing the pressure increase.

If the connection pressure exceeds the max. connection pressure:
► Immediately close isolating valve.
► Do not start plant.
► Notify system operator.

If the connection pressure does not maintain the min. connection pressure:
► Do not start plant.
► Notify system operator.



7.1.3 Check soundness of gas valve train

Carry out soundness test:
- prior to commissioning,
- after all service and maintenance work.

	First test phase	Second and third test phase
Test pressure	100 mbar ±10 %	100 mbar ±10 %
Waiting time for pressure equalisation	5 minutes	5 minutes
Test time	5 minutes	5 minutes
Permissible pressure loss	1 mbar	5 mbar

First test phase



Only in conjunction with W-MF and gas connection pressure > 150 mbar
In the first test phase, the testing device must be connected to the pressure regulator.
► Check soundness of gas valve train, see additional sheet (print No. 835109xx).

In the first phase the valve train section from the gas isolating valve up to the first valve of the multifunction assembly is tested.

► Switch off burner.
► Close gas isolating valve.
► Connect test equipment.
► Open test point between valve 1 and valve 2.
► Carry out test to table.

Second test phase


In the second phase the interspace in the multifunction assembly is tested.

► Connect test equipment.
► Carry out test to table.

Third test phase

In the third phase the valve train section from the multifunction assembly up to the gas butterfly valve is tested.


- ► Remove mixing head [ch. 9.3].
- ► Fit blanking plate ④.
- ► Fit mixing head.
- ► Connect test equipment.
- ► Carry out test to table.
- ► Close all test points.
- ► Remove blanking plate.



① First test phase
② Second test phase
③ Third test phase
④ Blanking plate

Fourth test phase


In the fourth test phase, the joint to the mixing head ① is tested for soundness. The test phase can only be carried out during or after burner commissioning.
A leak detecting spray or electronic gas detector should be used for testing.



Use only leak detecting foam solutions, which do not cause corrosion, see DVGW-TRGI, worksheet G 600.

- ► Check all components, intersections and test points of the gas valve train between multifunction assembly and burner.
- ► Document result of the soundness test on the engineers report.


Test points



① Pressure into valve 1
② Pressure between valve 1 and valve 2
③ Pressure after valve 2

7.1.4 Purging the gas valve train

- ▶ Open test point into valve 1 [ch. 7.1.3].
- ▶ Connect an approved vent hose to the test point.
- ▶ Vent hose must lead to atmosphere.
- ▶ Slowly open gas isolating valve.
- ✓ The gas/air mixture in the valve train vents via the hose to safe atmosphere.
- ▶ Close gas isolating valve.
- ▶ Remove vent hose and immediately close test point.
- ▶ Use a test burner to ensure no air is present in the valve train.



7.1.5 Preset pressure regulator

Determine setting pressure

Add the combustion chamber pressure in mbar to the setting pressure into the gas butterfly valve.

► Determine setting pressure from the table and note down.

The details given for calorific value H_i relate to 0 °C and 1013 mbar.

The table values have been calculated under ideal conditions. The values are therefore guide values for basic settings.


Full load [kW]	**Setting pressure into gas butterfly valve [mbar]**	**Min. connection pressure into isolating valve [mbar]** (low pressure supply)		
Nominal diameter valve train		¾"	1"	1"
Multifunction assembly W-MF SE		507	507	512
	Natural Gas E: H_i = 10.35 kWh/m³, d = 0.606			
80	8.5	–	13	11
90	8.5	–	13	11
100	8.5	–	13	11
110	8.5	–	14	12
120	8.5	–	14	13
130	8.9	–	15	13
140	9.3	–	15	13
150	9.6	–	16	14
160	9.8	–	16	15
170	10.1	–	16	15
180	10.3	–	16	15
190	10.6	–	17	16
200	10.9	–	18	16
	Natural Gas LL: H_i = 8.83 kWh/m³, d = 0.641			
80	11.0	–	15	13
90	11.0	–	15	13
100	11.0	–	15	14
110	11.0	–	16	14
120	11.0	–	16	15
130	11.4	–	17	16
140	11.7	–	18	16
150	12.2	–	18	17
160	12.7	–	19	17
170	13.2	–	20	18
180	13.6	–	21	18
190	14.0	–	22	19
200	14.4	–	23	20

Full load [kW]	Setting pressure into gas butterfly valve [mbar]	Min. connection pressure into isolating valve [mbar] (low pressure supply)		
Nominal diameter valve train		¾"	1"	1"
Multifunction assembly W-MF SE		507	507	512
	Liquid Petroleum Gas: H_i = 25.89 kWh/m³, d = 1.555 The selection is calculated for Propane, it can however, also be used for Butane.			
80	9.3	13	–	–
90	9.3	13	–	–
100	9.3	13	–	–
110	9.3	14	–	–
120	9.3	14	–	–
130	9.6	14	–	–
140	9.9	14	–	–
150	10.2	15	–	–
160	10.4	15	–	–
170	10.7	16	–	–
180	11.0	17	–	–
190	11.9	18	–	–
200	12.8	19	–	–

Preset setting pressure

Only in conjunction with W-MF and gas connection pressure > 150 mbar
The pre-pressure must be set to approx. 90 mbar.
► Set FRS pressure regulator, see additional sheet (print No. 835109xx).

► Preset setting pressure determined at multifunction assembly.



7.1.6 Setting values

Set mixing head relative to the combustion heat rating required. For this, the diffuser setting and the air damper setting should be matched.


Determine diffuser setting and air damper setting

Do not operate the burner outside of the capacity graph [ch. 3.4.6].

► Determine the diffuser setting (dimension X) and air damper setting required from the diagram and note down.

Example

	Example 1	Example 2
Burner capacity required	90 kW	150 kW
Combustion chamber pressure	0.8 mbar	1.3 mbar
Diffuser setting (dimension X)	0 mm	5.5 mm
Air damper setting	43°	> 80°




① Combustion heat rating [kW]
② Combustion chamber pressure [mbar]
③ Air damper setting
④ Diffuser setting [mm] (dimension X)
⑤ Air damper setting range with diffuser setting closed (X = 0 mm)
⑥ Setting range dimension X with air damper setting > 80°

Set diffuser


With dimension X = 0mm the indicating bolt is flush with nozzle assembly cover.

► Turn screw ①, until dimension X equals the value determined.



Set air damper limit switch

► Check and if necessary adjust position of limit switches ST0, ST1 and ZL.
► Set air damper setting determined at limit switch ST2.



7.1.7 Preset gas and air pressure switch

The presetting of the pressure switches is only valid during commissioning. Once commissioning has been completed the pressure switches must be set correctly [ch. 7.3].

Air pressure switch	approx. 3.5 mbar
Low gas pressure switch/valve proving gas pressure switch	12 mbar
High gas pressure switch (optional)	approx. twice control pressure

7.2 Adjusting the burner



DANGER

Risk of electric shock
Touching the ignition device can lead to electric shock.
► Do not touch ignition device during the ignition process.


► Check flame signal during commissioning [ch. 7.1.1].

1. Check sequence of operation

► Open gas isolating valve.
✓ Pressure in gas valve train increases.
► Close isolating valve.
► Switch on voltage supply.
✓ Illuminated push button lights up red.
► Press illuminated push button for 1 second.
✓ Burner starts in accordance with the programme sequence [ch. 3.3.4].
► Check sequence of operation:
- Valves open.
- Gas pressure switch reacts.
- Burner start is interrupted.
- Low gas programme starts, the illuminated button flashes red.

2. Adjust setting pressure


► Open test point for setting pressure and connect pressure measuring device.



► Open gas isolating valve.
► Unplug 4 pole connection plug.
► Press illuminated push button on combustion manager.
✓ Low gas program is reset.
✓ Burner starts in line with the sequence of operation and stops in ignition load ZL Gas equal to partial load ST1.
► Preset setting pressure determined at multifunction assembly [ch. 7.1.5].

3. Adjust ignition load

- ► Check combustion values in ignition load.
- ► Set O_2 content of 4 … 5 % via gas butterfly valve screw 1.



4. Adjust full load

- ► Select variation 1 or 2 depending on rating selected from setting diagram:

	Variation 1	Variation 2
Setting diagram		
Actuator	less than 80°	greater than 80°
Diffuser	0 mm	greater than 0 mm
Set combustion via:	Multifunction assembly setting pressure	Diffuser
Set capacity via:	Air damper setting ST2	Multifunction assembly setting pressure

Heat demand required for full load (contact T6/T8 closed).
- ► Plug in 4 pole connection plug.
- ✓ Burner drives to full load.

When adjusting, the ratings data given by the boiler manufacturer and the capacity graph of the burner should be observed [ch. 3.4.6].

Variation 1

Exit full load, if the air damper setting has to be adjusted. Any adjustment to the air damper setting for full load must be made in partial load.

- ► Check CO content of combustion and if necessary adjust combustion via the multifunction assembly setting pressure.
- ► Calculate gas throughput (operating volume V_B) required [ch. 7.6].
- ► Optimise air damper setting ST2 until gas throughput (V_B) is achieved.
- ► Check combustion values
- ► Determine combustion limit and set excess air via multifunction assembly setting pressure [ch. 7.5].
- ► Determine gas throughput once more and adjust if necessary.
- ► Re-set excess air.

Variation 2

- ► Check CO content of combustion and if necessary adjust combustion values via diffuser.
- ► Calculate gas throughput (operating volume V_B) required [ch. 7.6].
- ► Optimise setting pressure until gas throughput (V_B) is achieved.
- ► Check combustion values
- ► Determine combustion limit and set excess air via diffuser [ch. 7.5].
- ► Determine gas throughput once more and adjust if necessary.
- ► Re-set excess air.

5. Adjust partial load


The following steps must only be carried out for two stage operation. For single stage operation continue with step 7.

Exit partial load, if the air damper setting has to be adjusted. Any adjustment to the air damper setting for partial load must be made in full load.

- ► Define partial load, whilst:
  - observing data provided by boiler manufacturer,
  - observing the burner capacity graph [ch. 3.4.6].
- ► Set partial load via limit switch ST1.
- ► Unplug 4 pole connection plug.
- ✓ Burner drives to partial load.
- ► Check combustion values
- ► Determine combustion limit and if necessary re-set excess air via gas butterfly screws.
- ► Observe operational range of gas butterfly screws.

screw	Operational range
3	50° … 80°
2	20° … 50°
1	0° … 20°

Factory setting: 3 rotations OPEN.



- ► Determine gas throughput and if necessary adjust.
- ► Re-set excess air.

6. Check full load

Adjustments to the gas setting screws in partial load can lead to combustion value changes in full load.

- ► Drive to full load.
- ► Check combustion values and if necessary adjust via gas setting screws whilst observing the operational range of the gas butterfly screws.

7. Check start behaviour



For single stage operation only
If changing the ignition load setting ZL Gas, set limit switch ST1 to the same value as ZL Gas.

- ► Switch off and restart burner.
- ► Check start behaviour and if necessary correct ignition position.

If the ignition position has been altered:

- ► Re-check start behaviour.

7.3 Set pressure switches

7.3.1 Set gas pressure switch

Low gas pressure switch/valve proving gas pressure switch

The switch point must be checked and if necessary adjusted during commissioning.


- ► Connect pressure measuring device to test point ① of the low gas pressure switch.
- ► Start burner and drive to full load.
- ► Slowly close gas isolating valve until either:
  - the O_2 content in the flue gas increases to above 7 %,
  - the flame stability considerably worsens,
  - the CO content increases,
  - the gas pressure reaches 12 mbar,
  - or the gas flow pressure drops to 50 %.
- ► Determine gas pressure.
- ► Slowly open gas isolating valve.
- ► Set the pressure determined as switch point at the setting cam ②, minimum value 12 mbar.

Check switch point

- ► Restart the burner.
- ► Slowly close gas isolating valve.
- ✓ If the low gas program starts, the gas pressure switch has been set correctly.
- ✓ If a lockout occurs or if the combustion reaches a critical condition, the low gas pressure switch reacts too late.

If lockout occurs:

- ► Increase switch point at setting cam ②.
- ► Slowly open gas isolating valve.
- ► Re-check switch point.



Set (optional) high gas pressure switch

- ► Set high gas pressure switch to 1.3 × $P_{Gas\ full\ load}$ (flow pressure at full load).

7.3.2 Set air pressure switch


The switch point must be checked and if necessary adjusted during commissioning.

- ▶ Connect pressure measuring device for differential pressure measurement.
- ▶ Start the burner.
- ▶ Carry out differential pressure measurement across the whole capacity range of the burner and determine the lowest differential pressure.
- ▶ Calculate switch point (80 % of release pressure or lowest differential pressure).
- ▶ Set the switch point determined at the setting cam ①.

Example

Lowest differential pressure	4.4 mbar
Switch point air pressure switch (80 %)	4.4 mbar × 0.8 = 3.5 mbar

Site specific influences on the air pressure, (e g. by the flue gas system, heat exchanger, installation location or air supply) may make it necessary to vary the setting of the air pressure switch.



7.4 Concluding work

- ▶ Check control and safety devices.
- ▶ Remove gas pressure measuring devices and close all test points.
- ▶ Conclude valve proving of gas valve train (fourth test phase) [ch. 7.1.3].
- ▶ Enter combustion values and settings in the commissioning record and/or test sheet.
- ▶ Mount cover on burner.
- ▶ Inform the operator about the use of the equipment.
- ▶ Hand the installation and operating manual to the operator and inform him that this should be kept with the appliance.
- ▶ Point out to operator that the installation should be serviced annually.

7.5 Check combustion

Determine excess air

- ► Slowly close air damper(s) in the relevant stage, until the combustion limit is reached (CO content approx. 100 ppm).
- ► Measure and document O_2 content.
- ► Read air number (λ).

Increase air number to ensure sufficient excess air:
- by 0.15 … 0.2 (equates to 15 … 20 % excess air),
- by more than 0.2 for more difficult conditions, such as:
  - dirty combustion air,
  - fluctuating intake temperature,
  - fluctuating chimney draught.

Example

$$\lambda + 0.15 = \lambda^*$$

- ► Set air number (λ*), do not exceed CO content of 50 ppm.
- ► Measure and document O_2 content.

Check flue gas temperature

- ► Check flue gas temperature.
- ► Ensure that the flue gas temperature complies with the data provided by the boiler manufacturer.
- ► If necessary adjust flue gas temperature, e g.:
  - Increase burner capacity in partial load to avoid condensation in the flue gas ducts, except on condensing units.
  - Reduce burner capacity in full load to improve efficiency.
  - Adjust heat exchanger to the data provided by the manufacturer.

Determine flue gas losses

- ► Drive to full load.
- ► Measure combustion air temperature (t_L) near the air damper(s).
- ► Measure oxygen content (O_2) and flue gas temperature (t_A) at the same time at one point.
- ► Determine flue gas losses using the following formula:

$$q_A = (t_A - t_L) \cdot \left(\frac{A_2}{21 - O_2} + B\right)$$

q_A Flue gas losses [%]

t_A Flue gas temperature [°C]

t_L Combustion air temperature [°C]

O_2 Volumetric content of oxygen in dry flue gas [%]

Fuel factors	Natural Gas	Liquid Petroleum Gas
A2	0,66	0,63
B	0.009	0.008

7.6 Calculate gas throughput

Formula symbol	Explanation	Example values
V_B	Operating volume [m^3/h] Volume measured at gas meter at current pressure and temperature (gas throughput).	–
V_N	Standard volume [m^3/h] Volume gained by gas at 1013 mbar and 0 °C.	–
f	Conversion factor	–
Q_N	Heat rating [kW]	200 kW
η	Boiler efficiency (e. g. 92 % ≙ 0.92)	0,92
H_i	Calorific value [kWh/m^3] at 0 °C and 1013 mbar	10.35 kW/m^3 (Natural Gas E)
t_{Gas}	Gas temperature at gas meter [°C]	10 °C
P_{Gas}	Pressure at gas meter [mbar]	25 mbar
P_{Baro}	Barometric air pressure [mbar], see table	500 m ≙ 955 mbar
V_G	Gas throughput determined at gas meter	0.74 m^3
T_M	Measuring time [seconds]	120 seconds

Calculate normal volume

► Calculate the normal volume (V_N) using the following formula.

$$V_N = \frac{Q_N}{\eta \cdot H_i} \qquad V_N = \frac{200\ kW}{0{,}92 \cdot 10.35\ kW/m^3} = 21.0\ m^3/h$$

Calculate conversion factor

► Determine gas temperature (t_{Gas}) and pressure (P_{Gas}) at gas meter.
► Determine barometric air pressure (P_{Baro}) from table.

Height above sea level [m]	0	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300
P_{Baro} [mbar]	1013	1001	990	978	966	955	943	932	921	910	899	888	877	866

► Calculate conversion factor (f) using the following formula.

$$f = \frac{P_{Baro} + P_{Gas}}{1013} \cdot \frac{273}{273 + t_{Gas}} \qquad f = \frac{955 + 25}{1013} \cdot \frac{273}{273 + 10} = 0.933$$

Calculate operating volume (gas throughput) required

$$V_B = \frac{V_N}{f} \qquad V_B = \frac{21.0\ m^3/h}{0.933} = 22.5\ m^3/h$$

Determine current operating volume (gas throughput)

► Measure gas throughput (V_G) at gas meter, measuring time (T_M) should be a minimum of 60 seconds.
► Calculate operating volume (V_B) using the following formula.

$$V_B = \frac{3600 \cdot V_G}{T_M} \qquad V_B = \frac{3600 \cdot 0.74\ m^3}{120\ s} = 22.2\ m^3/h$$

8 Shutdown

For breaks in operation:
- ► Switch off burner.
- ► Close fuel shut off devices.

9 Servicing

9.1 Notes on servicing



DANGER

Risk of explosion due to leaking gas
Improper service work can lead to escaping gas and explosion.
- ► Close fuel shut off devices prior to starting work.
- ► Care should be taken when dismantling and assembling gas carrying components.
- ► Close the screws on the test points ensuring the tests points are sealed.



DANGER

Risk of electric shock
Working on the device when voltage is applied can lead to electric shock.
- ► Isolate the device from the power supply prior to starting any work.
- ► Safeguard against accidental restart.



WARNING

Danger of getting burned on hot components
Hot components can lead to burns.
- ► Allow components to cool.

Servicing must only be carried out by qualified personnel. The combustion plant should be serviced annually. Depending on site conditions more frequent checks may be required.

Components, which show increased wear and tear or whose design lifespan is or will be exceeded prior to the next service should be replaced as a precaution.

The design lifespan of the components is listed in the service plan [ch. 9.2].



Weishaupt recommends a service contract is entered into to ensure regular inspections.

The following components must only be replaced and must not be repaired:
- combustion manager
- flame sensor
- actuator
- multifunction assembly
- pressure regulator
- pressure switch

Prior to every servicing

- ► Inform the operator about the extent of service work to be carried out.
- ► Switch off mains switch of installation and safeguard against accidental reactivation.
- ► Close fuel shut off devices.
- ► Remove cover.
- ► Unplug boiler control connection plug from combustion manager.

Following servicing



DANGER

Risk of electric shock
Touching the ignition device can lead to electric shock.
- ► Do not touch ignition device during the ignition process.

- ► Check tightness of gas carrying components.
- ► Check function of:
  - ignition,
  - flame monitoring,
  - gas carrying components (gas connection pressure and setting pressure),
  - pressure switch,
  - control and safety devices.
- ► Check combustion values, if necessary re-adjust the burner.
- ► Enter combustion values and settings in the commissioning record.
- ► Refit cover.

9.2 Service plan

Components	Criteria / design lifespan[1]	Service procedure
Fan wheel	Soiling	▶ Clean
	Damage	▶ Replace
Air duct	Soiling	▶ Clean
Air damper	Soiling	▶ Clean
Air pressure switch	Switch point	▶ Check
	250 000 burner starts or 10 years[2]	▶ Replace
Ignition cable	Damage	▶ Replace
Ignition electrode	Soiling	▶ Clean
	Damage/wear	▶ Replace
Combustion Manager	250 000 burner starts or 10 years[2]	▶ Replace
Ionisation cable	Damage	▶ Replace
Ionisation electrode	Soiling	▶ Clean
	Damage/wear	▶ Replace Recommendation: at least every 2 years
Flame tube/diffuser	Soiling	▶ Clean
	Damage	▶ Replace
Multifunction assembly with valve testing system (valve proving)	Fault identified	▶ Replace
Multifunction assembly without valve testing system (valve proving)	Function / soundness less than DN 25: 200 000 burner starts or 10 years[2] DN 25 to DN 65: 100 000 burner starts or 10 years[2]	▶ Replace
Breather plug multifunction assembly	Soiling	▶ Replace
Filter insert multifunction assembly	Soiling	▶ Replace
Gas pressure regulator	Setting pressure	▶ Check
	Function / soundness	▶ Replace
	15 years	▶ Replace
Gas pressure switch	Switch point	▶ Check
	50 000 burner starts or 10 years[2]	▶ Replace

[1] The specified design lifespan applies for typical use in heating, hot water and steam systems as well as for thermal process systems to EN 746.
[2] If a criterion is reached, carry out maintenance measures.

9.3 Removing and refitting mixing head

Observe notes on servicing [ch. 9.1].

DANGER


Risk of explosion due to leaking gas
It is possible for gas to leak out if the gasket ③ is seated incorrectly.
- ► Following work on the mixing head, ensure the gasket is clean and seated correctly, if necessary replace.
- ► Check for leaks, see Fourth test phase [ch. 7.1.3].

Removing

- ► Unplug ionisation cable ⑤.
- ► Unplug ignition cable ①.
- ► Undo screws ④.
- ► Turn mixing head ② to the left up to the recess and remove.

Refitting

- ► Refit mixing head in reverse order ensuring correct alignment and cleanliness of gasket ③.



9.4 Set mixing head

Observe notes on servicing [ch. 9.1].

The distance between diffuser and flame tube front edge S1 can not be measured with the burner mounted. This is only possible indirectly with the mixing head removed, with dimension Lx.

Dimension Lx changes according to the combustion head extension used.


- ► Remove mixing head [ch. 9.3].
- ► Turn setting screw ① until it is flush with the nozzle assembly cover (dimension X = 0 mm).
- ► Check dimension Lx.

If the value measured deviates from dimension Lx:

- ► Undo screws ②.
- ► Adjust flame tube ③ until dimension Lx has been reached.
- ► Re-tighten screws ②.

If the screws ② have been loosened:


- ► Check position of electrodes and gas orifices ④.



9.5 Set ionisation and ignition electrodes

Observe notes on servicing [ch. 9.1].

- ► Remove mixing head [ch. 9.3].
- ► Undo screw ①.
- ► Set ignition electrode and re-tighten screw.
- ► Undo screw ②.
- ► Set ionisation electrode and re-tighten screw.




9.6 Service position

Observe notes on servicing [ch. 9.1].

The burner mounted rotated by 180° cannot be placed into the service position.

- ► Remove mixing head [ch. 9.3].
- ► Remove actuator plug ③.
- ► Hold housing cover and remove screws ①.
- ► Place housing cover into service position ②.



9.7 Removing and refitting fan wheel


Observe notes on servicing [ch. 9.1].

Removing

- ► Place housing cover into service position [ch. 9.6].
- ► Remove grub screw ① and remove fan wheel.

Refitting


- ► Refit fan wheel in reverse order and
  - ensure correct alignment on the motor shaft ②,
  - screw in new grub screw ①,
  - turn fan wheel to ensure it moves freely.



9.8 Remove burner motor

Observe notes on servicing [ch. 9.1].

- ► Remove fan wheel [ch. 9.7].
- ► Unplug plug number 3 and 11.
- ► Disconnect + and - hoses.
- ► Undo screws ① and remove air pressure switch.
- ► Hold motor and remove screws ②.
- ► Remove motor.



9.9 Removing and refitting air damper actuator

Observe notes on servicing [ch. 9.1].

Removing


- ► Remove actuator plug ① from combustion manager.
- ► Remove screws ②.
- ► Remove actuator.

Refitting

CAUTION

Damage to the actuator caused by turning the hub
Actuator could be damaged.
- ► Do not turn hub manually or with tool.

- ► Place actuator into the star shaped groove ③.
- ► Secure actuator.
- ► Plug in actuator plug ① at the combustion manager.



9.10 Removing and refitting angle drive


Observe notes on servicing [ch. 9.1].

Removing

- ► Remove air damper actuator [ch. 9.9].
- ► Pull drive rod ③ from the gas butterfly valve ⑧ and remove.
- ✓ Air damper is opened by the force of the spring.
- ► Remove frame ④.
- ► Remove angle drive ⑤.

Refitting

- ► Remove intake housing [ch. 9.12].
- ► Open air damper ⑥ until position ⑦ has been reached and hold tight.
- ► Fit angle drive to shaft.
- ► Secure angle drive.
- ► Mount intake housing.
- ► Fit frame ④.
- ► Place drive rod ③ into actuator.
- ► Turn indicator ① to CLOSED position and hold.
- ► Place actuator with drive rod ③ into the star shaped groove ② and secure.
- ► Engage drive rod on gas butterfly valve ⑧, ensuring correct alignment.



9.11 Removing and refitting gas butterfly valve


Observe notes on servicing [ch. 9.1].

Removing

- ► Remove screws ③.
- ► Unscrew flange with double nipple ④.
- ► Remove mixing head [ch. 9.3].
- ► Remove drive rod ⑥.
- ► Remove screws ① and remove gas butterfly valve ②.

Refitting

- ► Refit gas butterfly valve ② in reverse order and:
  - ensure correct alignment of drive rod ⑥ with gas butterfly valve,
  - secure flange to multifunction assembly whilst ensuring correct seating of O ring ⑤ on the flange.




- ► Carry out soundness test [ch. 7.1.3].

9.12 Removing and refitting air regulator

Observe notes on servicing [ch. 9.1].

Removing

- ► Remove bolts ①.
- ► Remove burner from heat exchanger [ch. 4.2].
- ► Remove actuator plug ⑥.
- ► Remove bolts ②.
- ► Remove intake housing ⑤.
- ► Remove bolts ④.
- ► Remove air regulator ③.



Refitting


- ► Refit air regulator in reverse order.
- ► Carry out soundness test [ch. 7.1.3].

9.13 Replacing coil on multifunction assembly

Observe notes on servicing [ch. 9.1].

Ensure correct voltage and solenoid number when replacing the solenoid coil.

- ► Undo screw ①.
- ► Remove cap ②.
- ► Replace solenoid coil ③.




9.14 Replace breather plug of multifunction assembly

Observe notes on servicing [ch. 9.1].

A breather plug with integrated filter is fitted to protect the breather orifice against soiling.

► Replace breather plug ①.



9.15 Removing and refitting filter insert of multifunction assembly

Observe notes on servicing [ch. 9.1].


Ensure no dirt enters the multifunction assembly when removing and replacing the filter insert.

Removing

- ► Remove screws ④.
- ► Remove cover ③.
- ► Remove filter insert ①.
- ► If necessary replace filter insert ① and seal ②.

Refitting

- ► Refit in reverse order ensuring correct alignment of filter ① and seal ②.




- ► Carry out soundness test [ch. 7.1.3].
- ► Vent gas valve train [ch. 7.1.4].

9.16 Replacing the fuse

Observe notes on servicing [ch. 9.1].

- ► Remove all plugs from the combustion manager.
- ► Remove screws from the combustion manager.
- ► Remove combustion manager.
- ► Replace fuse (T6.3H, IEC 127-2/5).




10 Troubleshooting

10.1 Procedures for fault conditions

The combustion manager recognises irregularities of the burner and indicates these with the illuminated push button.

The following conditions can occur:
- illuminated push button off [ch. 10.1.1],
- illuminated push button red [ch. 10.1.2],
- illuminated push button flashes [ch. 10.1.3].



10.1.1 Illuminated push button off

The following faults may be corrected by the operator:

Fault	Cause	Rectification
Burner not operating	External fuse has tripped(1	▶ Check fuse.
	Heating switch is set to Off	▶ Switch on heating switch.
	Temperature limiter or pressure limiter on heat exchanger has triggered(1	▶ Reset temperature limiter or pressure limiter on heat exchanger.
	Low water safety interlock on heat exchanger has triggered(1	▶ Top up water. ▶ Reset low water safety interlock on heat exchanger.
	Temperature regulator or pressure regulator on heat exchanger has been set incorrectly	▶ Adjust temperature regulator or pressure regulator on heat exchanger.
	Boiler or heating circuit control is not functioning or has not been set correctly	▶ Check function and setting of boiler or heating circuit control.

(1 Notify your heating contractor or Weishaupt Customer Service if the problem occurs repeatedly.

10.1.2 Illuminated push button red

A burner fault has occurred. The burner is in lockout. Prior to resetting, the error code can be called up and used to control the cause of the fault.

Read error code

Only 5 seconds after a fault occurred can it be been analysed and read.

- ► Press illuminated push button for 5 seconds.
- ✓ Illuminated push button briefly lights up orange.
- ✓ Illuminated push button flashes red.
- ► Count between the flashing pauses and flashing signals and note down.
- ► Rectify cause of fault, see table.

Resetting



WARNING

Damage resulting from incorrect fault repair
Incorrect fault repair can cause damage to the equipment and injure personnel.
- ► Do not carry out more than 2 lockout resets successively.
- ► Faults must be rectified by qualified personnel.

- ► Press illuminated push button for 1 second.
- ✓ Red signal extinguishes.
- ✓ Burner has been reset.

Error codes with lockout

The following faults must only be rectified by qualified personnel:

Fault codes	Fault	Cause	Rectification
2 x flashing No flame, end of safety time	No ignition	Ignition electrode set incorrectly	▶ Set ignition electrode [ch. 9.5]
		Ignition electrode dirty or wet	▶ Clean ignition electrode
		Ceramic insulator defective	▶ Replace ignition electrode.
		Ignition cable defective	▶ Replace ignition cable
		Ignition unit defective	▶ Replace ignition unit
	Double gas valve does not open	Cable defective	▶ Check cable, if necessary replace
		Coil defective	▶ Replace coil [ch. 9.13]
	Combustion manager does not detect a flame signal	No ionisation current present or insufficient	▶ Measure ionisation current [ch. 7.1.1] ▶ Set ionisation electrode [ch. 9.5] ▶ Check contact resistance (terminal, plug) ▶ Correct burner setting ▶ When using an unearthed mains supply (control transformer) the pole which is to be used as neutral conductor must be earthed
		Ionisation electrode worn	▶ Replace ionisation electrode
		Ionisation cable defective	▶ Replace cable
Flashing 3 times Air pressure switch fault	Air pressure switch does not react	Hoses not attached tightly	▶ Check hoses on air pressure switch
		Air pressure switch set incorrectly	▶ Set air pressure switch [ch. 7.3.2]
		Cable defective	▶ Check cable, if necessary replace
		Air pressure switch defective	▶ Check air pressure switch, if necessary replace
	Burner motor does not run	Capacitor defective	▶ Replace capacitor
		Cable defective	▶ Check cable, if necessary replace
		Burner motor defective	▶ Check burner motor, if necessary replace
Flashing 4 times Flame simulation/ extraneous light	Flame signal prior to or after operation	Ionisation current present	Extraneous light detection from 0.8 µA ▶ Find and eliminate perturbation
		Ionisation electrode defective	▶ Check the ionisation electrode, replace if necessary

The following faults must only be rectified by qualified personnel:

Fault codes	Fault	Cause	Rectification
Flashing 6 times Actuator fault	Actuator does not reach target position within 10 seconds	Actuator plug unplugged	▶ Plug in actuator plug
		Actuator defective	▶ Check actuator, replace if necessary
			▶ Check position of limit switches
		Setting of limit switches incorrect Gas valve / air damper blocked	▶ Check freedom of movement of gas valve and air damper
Flashing 7 times Flame failure during operation (partial load)	Flame signal insufficient	Burner setting incorrect	▶ Check burner setting ▶ Check flame signal
		Ionisation electrode soiled	▶ Clean ionisation electrode
		Ionisation electrode set incorrectly	▶ Set ionisation electrode [ch. 9.5]
		Ionisation electrode defective	▶ Check the ionisation electrode, replace if necessary
Flashing 8 times Gas pressure switch fault	Gas pressure switch does not react	Gas pressure switch set incorrectly	▶ Set gas pressure switch [ch. 7.3.1]
		Gas pressure switch defective	▶ Check gas pressure switch, if necessary replace
Flashing 9 times Flame failure during operation (full load)	Flame signal insufficient	Burner setting incorrect	▶ Check burner setting ▶ Check flame signal
		Ionisation electrode soiled	▶ Clean ionisation electrode
		Ionisation electrode set incorrectly	▶ Set ionisation electrode
		Ionisation electrode defective	▶ Check the ionisation electrode, replace if necessary
Flashing 10 times Combustion manager fault	Burner does not start	Parameters have been changed	▶ Reset burner [ch. 10.1.2]
		Combustion manager defective	▶ Reset burner [ch. 10.1.2], if fault reoccurs replace combustion manager

10 Troubleshooting

The following faults must only be rectified by qualified personnel:

Fault codes	Fault	Cause	Rectification
Flashing 12 times Valve proving fault First test phase	Valve 1 leaking	Gas valve train leaking	▶ Check soundness of gas valve train [ch. 7.1.3]
		Gas pressure switch set incorrectly	▶ Set gas pressure switch
		Gas pressure switch defective	▶ Check gas pressure switch, if necessary replace
		Multifunction assembly defective	▶ Replace multifunction assembly
Flashing 13 times Valve proving fault Second test phase	Valve 2 leaking	Gas valve train leaking	▶ Check soundness of gas valve train [ch. 7.1.3]
		Gas pressure switch set incorrectly	▶ Set gas pressure switch [ch. 7.3.1]
		Gas pressure switch defective	▶ Check gas pressure switch, if necessary replace
		Multifunction assembly defective	▶ Replace multifunction assembly

10.1.3 Illuminated push button flashes

An irregularity is present. The burner does not go to lockout. Once the fault has been rectified, the error code ceases.

Error codes without lockout

The following faults must only be rectified by qualified personnel:

Fault codes	Cause	Rectification
Flashing green/red	Flame signal at heat demand	▸ Find and eliminate perturbation
Flashing red/orange with pause	Excess voltage	▸ Check voltage supply
Flashing orange/red	Low voltage	▸ Check voltage supply
	Internal unit fuse (F7) faulty	▸ Replace fuse [ch. 9.16]
	Combustion manager fault	▸ Replace combustion manager
Flashing red	Low gas	▸ Check gas connection pressure ▸ Set gas pressure switch [ch. 7.3.1] ▸ Check gas pressure switch
orange, after 5 seconds red	Air pressure switch does not react	▸ Set air pressure switch [ch. 7.3.2] ▸ Check air pressure switch ▸ With ducted air intake air pressure switch, check air supply
Flashing green	Burner operation with weak flame signal	Minimum ionisation current 1.5 µA ▸ Check burner setting
	Ionisation electrode soiled	▸ Clean ionisation electrode
	Ionisation electrode defective	▸ Replace ionisation electrode
Glimmering red	OCI mode activated (not used)	▸ Press illuminated push button for more than 5 seconds ✓ Combustion manager changes to operating mode

10.2 Operating problems


The following faults must only be rectified by qualified personnel:


Observation	Cause	Rectification
Poor start behaviour of burner	Mixing pressure too high	▸ Reduce mixing pressure in ignition position
	Ignition electrode set incorrectly	▸ Set ignition electrode [ch. 9.5]
	Mixing head set incorrectly	▸ Set mixing head [ch. 9.4]
	Ignition load set incorrectly	▸ Set ignition load [ch. 7.2]
Combustion pulsating or burner booming	Mixing head set incorrectly	▸ Set mixing head [ch. 9.4]
	Incorrect combustion air quantity	▸ Adjust burner
Stability problems	Mixing pressure too high	▸ Decrease mixing pressure

11 Technical documentation


11.1 Wiring diagram

For special version observe wiring diagram supplied.





B10	Air pressure switch
B15	Temperature or pressure regulator
B16	Temperature or pressure regulator full load
F1	External fuse (max 16 AB)
F2	Temperature or pressure limiter
F7	Internal unit fuse (T6.3H, IEC 127-2/5)
M20	Air damper actuator
P6	Control lamp lockout (optional)
P11	Control lamp operation (optional)
S1	Operating switch
S3	Remote reset (optional)
①	Bridge for single stage operation
②	Bus interface (optional)



B1	Flame sensor
B31	Low gas pressure switch/valve proving gas pressure switch
C1	Motor capacitor
K32	double gas valve
K33	External valve LPG (optional)
M1	Burner motor
P11.1	Hours counter (optional)
T1	Ignition unit

11.2 Conversion table unit of pressure

Bar	Pascal			
	Pa	**hPa**	**kPa**	**MPa**
0.1 mbar	10	0.1	0,01	0.00001
1 mbar	100	1	0.1	0.0001
10 mbar	1 000	10	1	0.001
100 mbar	10 000	100	10	0,01
1 bar	100 000	1 000	100	0.1
10 bar	1 000 000	10 000	1 000	1

11.3 Appliance categories

Labelling of gas and dual fuel burners to EN 676

EN 676, "Forced draught burners for gaseous fuels", is used for the implementation of the basic requirements of the directive (EU) 2016/426.

EN 676 stipulate the following appliance categories for forced draught gas burners under Point 4.4.9:

I2R	for Natural Gas
I3R	for Liquid Petroleum Gas
II2R/3R	for Natural Gas / Liquid Petroleum Gas

The test gases listed under point 5.1.1, table 4 and the minimum test pressures determined and listed under point 5.1.2, table 5 are used to provide the evidence of service performance of the burner during type testing.

As -weishaupt- gas and dual fuel burners fulfil this requirement completely, the appliance category, as well as the test gases used with the permissible connection pressure range, are listed on the name plate when labelling the burner to point 6.2 . This clearly defines the suitability of the burner for use with second or third family gases.

On the basis of a type test report to ISO 17025 from an accredited test centre, the EU Type Testing Certificate to Directive (EU) 2016/426 also quotes the appliance category, the supply pressure and the country of destination.

EN 437, "Test gases - test pressures - appliance categories", describes the interrelationships and the special national characteristics relating to this subject in detail.

The following tables give an overview of the interrelationships between the R Categories and the nationally used appliance categories with their types of gas and connection pressures.

Alternative appliance category to I2R

Country of destination	Appliance category	Test gas	Connection pressure mbar
AL (Albania)	I2H	G 20	20
AT (Austria)	I2H	G 20	20
BA (Bosnia)	I2H	G 20	20
BE (Belgium)	I2E+, I2N, I2E(R)B	G 20 + G 25	Pressures 20 / 25
BG (Bulgaria)	I2H	G 20	20
BY (Belarus)			
CH (Switzerland)	I2H	G 20	20
CY (Cyprus)	I2H	G 20	20
CZ (Czech Republic)	I2H	G 20	20
DE (Germany)	I2ELL, I2E, I2L	G 20 / G 25	20
DK (Denmark)	I2H	G 20	20
EE (Estonia)	I2H	G 20	
ES (Spain)	I2H	G 20	20
FI (Finland)	I2H	G 20	20
FR (France)	I2Esi, I2E+, I2L	G 20 + G 25	Pressures 20 / 25
GB (United Kingdom)	I2H	G 20	20
GR (Greece)	I2H	G 20	20
HR (Croatia)	I2H	G 20	20
HU (Hungary)	I2H	G 20	20
IE (Ireland)	I2H	G 20	20
IS (Iceland)	I2H	G 20	20
IT (Italy)	I2H	G 20	20
LT (Lithuania)			
LU (Luxembourg)	I2E	G 20	20
LV (Latvia)			
MD (Moldova)	I2H	G 20	20
MK (Macedonia)	I2H	G 20	20
MT (Malta)	I2H	G 20	20
NL (The Netherlands)	I2L, I2EK	G 25	25
NO (Norway)	I2H	G 20	20
PL (Poland)	I2E	G 20 / GZ 410	20
PT (Portugal)	I2H	G 20	20
RO (Romania)	I2H	G 20	20
SE (Sweden)	I2H	G 20	20
SI (Slovenia)	I2H	G 20	20
SK (Slovakia)	I2H	G 20	20
SRB (Serbia)	I2H	G 20	20
TR (Turkey)	I2H	G 20	25
UA (Ukraine)	I2H	G 20	20

Alternative appliance category to I3R

Country of destination	Appliance category	Test gas	Connection pressure mbar
AL (Albania)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
AT (Austria)	I3B/P, I3P	G 30 + G 31	50
BA (Bosnia)	I3B/P	G 30	30 (28-30)
BE (Belgium)	I3+, I3P, I3B, I3B/P	G 30 + G 31	Pressures 28 - 30 / 37
BG (Bulgaria)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
BY (Belarus)			
CH (Switzerland)	I3B/P, I3+, I3P	G 30 + G 31	Pressures 28 - 30 / 37
CY (Cyprus)	I3B/P, I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
CZ (Czech Republic)	I3B/P, I3+, I3P	G 30 + G 31	Pressures 28 - 30 / 37
DE (Germany)	I3B/P, I3P	G 30 + G 31	50
DK (Denmark)	I3B/P	G 30 + G 31	30 (28 - 30)
EE (Estonia)	I3B/P	G 30	
ES (Spain)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
FI (Finland)	I3B/P	G 30 + G 31	30 (28 - 30)
FR (France)	I3+, I3P, I3B	G 30 G 31	Pressures 28 - 30 / 37 Pressures 112 / 148
GB (United Kingdom)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
GR (Greece)	I3B/P, I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
HR (Croatia)	I3B/P, I3P	G 30 + G31	50
HU (Hungary)	I3B/P	G 30 + G31	50
IE (Ireland)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
IS (Iceland)	I3B/P		
IT (Italy)	I3B/P, I3+, I3P	G 30 + G 31	Pressures 28 - 30 / 37
LT (Lithuania)			
LU (Luxembourg)	I3B/P	G 30	
LV (Latvia)			
MD (Moldova)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
MK (Macedonia)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
MT (Malta)	I3+, I3P, I3B	G 30 + G 31	Pressures 28 - 30 / 37
NL (The Netherlands)	I3B/P, I3P	G 30 + G 31	30 (28 - 30)
NO (Norway)	I3B/P	G 30 + G 31	30 (28 - 30)
PL (Poland)	I3B/P	G 30	
PT (Portugal)	I3+, I3P, I3B	G 30 G 31	Pressures 28 - 30 / 37 Pressures 50 / 67
RO (Romania)	I3B/P	G 30	
SE (Sweden)	I3B/P	G 30 + G 31	30 (28 - 30)
SI (Slovenia)	I3B/P	G 30	30
SK (Slovakia)	I3B/P	G 30	30
SRB (Serbia)	I3B/P, I3P	G 30 + G 31	20
TR (Turkey)	I3B/P	G 30 + G 31	30
UA (Ukraine)	I3B/P, I3P	G 30 + G 31	50

11 Technical documentation

Alternative appliance category to II2R/3R

Country of destination	Appliance category	Test gas	Connection pressure mbar	Test gas	Connection pressure mbar
AL (Albania)	II2H3+, II2H3P	G 20	20	G 31	30
AT (Austria)	II2H3B/P, II2H3P	G 20	20	G 30 + G 31	50
BA (Bosnia)	II2H3B/P	G 20	20	G 30	
BE (Belgium)	II2E+3P, II2H3B/P	G 20, G 25	Pressures 20 / 25	G 30 + G 31	Pressures 28 - 30 / 37
BG (Bulgaria)	II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
BY (Belarus)					
CH (Switzerland)	II1a2H, II2H3B/P, II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
CY (Cyprus)	II2H3B/P, II2H3+, II2H3P	G20	20	G 30 + G 31	Pressures 28 - 30 / 37
CZ (Czech Republic)	II2H3B/P, II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
DE (Germany)	II2ELL3B/P, II2E3B/P	G 20	20	G 30 + G 31	50
DK (Denmark)	II1a2H, II2H3B/P	G 20	G 20	G 30 + G 31	30
EE (Estonia)	II2H3B/P	G 20	20	G 30	30
ES (Spain)	II2H3P, II2H3+	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
FI (Finland)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
FR (France)	II2E+3+, II2E+3P, II2Esi3B/P	G 20	20	G 30 G 31	Pressures 28 - 30 / 37 Pressures 112 /148
GB (United Kingdom)	II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
GR (Greece)	II2H3B/P, II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
HR (Croatia)	II2H3B/P	G 20	20	G 30 + G 31	30 (28-30)
HU (Hungary)	II2H3B/P	G 20	20	G 30 + G 31	
IE (Ireland)	II2H3+, II2H3P	G 20	20		
IS (Iceland)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
IT (Italy)	II1a2H, II2H3B/P, II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 28 - 30 / 37
LT (Lithuania)					
LU (Luxembourg)	II2E3B/P	G 20	20	G 30 + G 31	
LV (Latvia)					
MD (Moldova)	II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 30 / 37
MK (Macedonia)	II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 30 / 37
MT (Malta)	II2H3+, II2H3P	G 20	20	G 30 + G 31	Pressures 30 / 37
NL (The Netherlands)	II2L3B/P, II2L3P, II2EK3B/P, II2EK3P	G 25	25	G 30 + G 31	30
NO (Norway)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
PL (Poland)	II2E3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
PT (Portugal)	II2H3+, II2H3P	G 20	20	G 30 G 31	Pressures 28 - 30 / 37 Pressures 50 / 67
RO (Romania)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
SE (Sweden)	II1a2H, II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
SI (Slovenia)	II2H3B/P	G 20	20	G 30	30
SK (Slovakia)	II2H3B/P	G 20	20	G 30	30
SRB (Serbia)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)
TR (Turkey)	II2H3B/P	G 20	25	G 30 + G 31	30 + 37
UA (Ukraine)	II2H3B/P	G 20	20	G 30 + G 31	30 (28 - 30)

12 Project planning

12.1 Continuous running fan or post-purge




DANGER

Fire hazard due to failure of the combustion air fan
Failure of the combustion air fan (e.g. due to a power failure or defective motor) during operation with continuous running fan or increased post-purge may result in back radiation or hot flue gases flowing back into the burner housing. This could cause a fire.

If fail-safe continuous ventilation or post-purge is required, take appropriate measures, such as:

- ▶ installing compressed air flushing on site with:
  - sufficiently large compressed air tank,
  - normally open compressed air valve.

13 Spares



1.01
1.02
1.03
1.04
1.05
1.06
1.07
1.08
1.09
1.10
1.11
1.12
1.12
1.13
1.14
1.15
1.15
1.16
1.17
1.17
1.18
1.19

13 Spares

Pos.	Description	Order No.
1.01	Cover complete	241 210 01 112
1.02	Screw M8 x 15	142 013 01 157
1.03	Washer 7 x 18	430 016
1.04	Burner housing	241 210 01 012
1.05	Intake housing complete	241 210 01 082
	– Screw 4 x 30 Torx-Plus	409 325
1.06	View port on hours counter cover	241 210 01 197
1.07	Treaded socket R$^{1}/_{8}$ GES6	453 017
1.08	Protective cap DN 6 SELF 50/2 CF	232 300 01 047
1.09	Grommet for connection cable	241 200 01 247
1.10	Grommet	241 400 01 177
1.11	Housing cover	241 210 01 227
1.12	Treaded socket R$^{1}/_{8}$ GES4	453 004
1.13	Bracket for cable	241 400 01 367
1.14	Stay bolt cover	241 210 01 207
1.15	Screw M8 burner housing	241 310 01 257
1.16	Burner flange	241 210 01 057
	– Screw M8 x 30 DIN 912	402 517
	– Washer 8.4 DIN 433	430 504
1.17	Stay bolt for burner flange	241 310 01 247
1.18	Flame tube WG20-C	
	– Standard	232 210 14 122
	– extended by 100 mm*	230 210 14 012
	– extended by 200 mm*	230 210 14 022
	– extended by 300 mm*	230 210 14 032
1.19	Flange gasket	241 210 01 107

* Only in conjunction with combustion head extension.

13 Spares



2.21
2.11
2.10
2.08
2.12
2.13
2.14
2.09
2.25
2.22
2.24
2.02
2.15
2.20
2.06
2.01
2.16
2.18
2.19
2.06
2.17
2.23
2.07
2.05
2.03
2.04
2.26
(1
2.28
2.27

13 Spares

Pos.	Description	Order No.
2.01	Motor ECK 04/A-2 230 V / 50 Hz	652 084
2.02	Screw M5 x 12	409 278
2.03	Capacitor set	713 476
2.04	Pressure switch LGW 10 A2 1 - 10 mbar	691 370
2.05	Connection flange for LGW	605 243
2.06	Hose 4.0 x 1.75 190 mm	232 050 24 057
2.07	Hose clamp 7.5	790 218
2.08	Fan wheel TLR-S 160 x 61.6-L-E S1 50Hz	241 210 08 032
2.09	Grub screw M8 x 8 w. an. cutter	420 550
2.10	Air guide	232 210 01 147
2.11	Air damper complete	241 210 02 022
2.12	Bearing for air damper shaft	241 110 02 107
2.13	Shaft air damper - angle drive	241 210 02 057
2.14	Angle drive	241 110 02 062
2.15	Screw 4 x 12 Torx-Plus Remform	409 320
2.16	Actuator STD 4.5, 24 V	651 102
2.17	Screw 4 x 35 Combi-Torx-Plus Remform	409 355
2.18	Frame for actuator	241 210 02 037
2.19	Screw 4 x 30 Torx-Plus Delta PT	409 325
2.20	Lever complete	232 210 02 012
2.21	Air regulator spring 2	241 210 02 072
2.22	Gas butterfly valve	
	– Natural Gas	232 210 25 010
	– Liquid Petroleum Gas	233 210 25 010
2.23	Spring 2	241 400 02 167
2.24	Seal connection channel	232 210 25 087
2.25	Treaded rod complete	232 210 25 012
2.26	Blanking plate valve proving	232 210 26 172
2.27	Adapter complete actuator rotated 180°	230 110 02 012
2.28	Lever complete actuator rotated 180°	230 110 02 022

(1 Only if rotated 180°.

13 Spares



3.01
3.03
3.02
3.04
3.05
3.08
3.06
3.09
3.07
3.19
3.18
3.17
3.17
3.13
3.14
3.15
3.10
3.12
3.11
3.16
3.21
3.22
3.20

13 Spares

Pos.	Description	Order No.
3.01	Mixing head WG20N/1-C cpl. (Natural Gas)	
	– Standard	232 210 14 052
	– extended by 100 mm*	230 210 14 072
	– extended by 200 mm*	230 210 14 082
	– extended by 300 mm*	230 210 14 092
	Mixing head WG20F/1-C cpl. (LPG)	
	– Standard	233 210 14 012
	– extended by 100 mm*	230 210 14 132
	– extended by 200 mm*	230 210 14 142
	– extended by 300 mm*	230 210 14 152
3.02	Lock housing complete	232 210 14 022
3.03	Mixing tube WG20N/1-C cpl. (Natural Gas)	
	Ø internal 32 mm	
	– Standard	232 210 14 082
	– extended by 100 mm*	230 210 14 042
	– extended by 200 mm*	230 210 14 052
	– extended by 300 mm*	230 210 14 062
	Mixing tube WG20F/1-C cpl. (LPG)	
	Ø internal 18 mm	
	– Standard	233 210 14 022
	– extended by 100 mm*	230 210 14 102
	– extended by 200 mm*	230 210 14 112
	– extended by 300 mm*	230 210 14 122
3.04	Nozzle element	232 200 14 467
3.05	Screw M4 x 16 Torx-Plus 20IP	409 224
3.06	Diffuser 36 x 95	232 200 14 417
3.07	Nozzle insert	232 200 14 397
3.08	Screw M4 x 8 Torx-Plus 20IP	409 235
3.09	Bracket for electrodes	232 200 14 437
3.10	Ignition electrode isolator 6 x 80	232 200 14 217
3.11	Sensor electrode	232 100 14 207
3.12	Ignition and sensor cable	
	– 380 mm (Standard)	232 110 11 032
	– 480mm (for 100 mm extension)*	230 110 11 082
	– 600mm (for 200 mm extension)*	232 310 11 042
	– 700mm (for 300 mm extension)*	232 400 11 042
3.13	Carrier	232 200 14 037
3.14	Carrier	232 200 14 047
3.15	O ring 32 x 3 NBR70 ISO 3601	445 095
3.16	Adjusting screw	232 210 14 047
3.17	Hexagonal nut M8 left DIN 934 -8	411 413
3.18	Spring washer A5 DIN 137	431 613
3.19	Hexagonal nut M5 DIN 985	411 203
3.20	Screw G⅛A DIN 908	409 004
3.21	Sealing ring 10 x 13.5 x 1.5 DIN 7603	441 033
3.22	View port glass	241 400 01 377

* Only in conjunction with combustion head extension.


13 Spares



13 Spares

Pos.	Description	Order No.
4.01	Combustion manager W-FM10 230 V / 50/60 Hz	600 475
	– Micro fuse T6.3H, IEC 127-2/5	483 011 22 457
4.02	Adapter ring 22 x 4 for extension	600 358
4.03	Reset button extension AGK20.19	600 357
4.04	Cover clip AGK63	600 312
4.05	Plug unit ST18/7	716 549
4.06	Plug unit ST18/4	716 546
4.07	Plug-in switch ST18/4 version Z	130 103 15 012
4.08	Ignition unit type W-ZG01603 229 230 V 100 VA	603 229
4.09	Closing plug for ignition unit	603 224
4.10	Screw M4 x 42 Combi-Torx-Plus 20IP	409 260
4.11	Plug cable No. 3 fan motor	241 050 12 062
4.12	Plug cable No. 5 W-MF	232 110 12 052
4.13	Plug cable No. 11 air pressure switch	232 110 12 022
4.14	Plug cable No.12 gas pressure switch	232 050 12 022
4.15	Ionisation cable No. 13	232 310 12 012

13 Spares



13 Spares

Pos.	Description	Order No.
5.01	Double nipple R1 x 80 with Loctite	139 000 26 747
5.02	Elbow A1-1-Zn-A	453 123
5.03	Double nipple R1 x 50 with Loctite	139 000 26 737
5.04	Flange W-MF	
	– 507 Rp1	605 233
	– 512 Rp1	605 228
5.05	Pressure test nipple $G^1/_8$ A	453 001
5.06	O ring	
	– 57 x 3 W-MF 507	445 519
	– 75 x 3.5 W-MF 512	445 520
5.07	Multifunction assembly	
	with gas pressure switch	
	– W-MF SE 507 S22 230V	605 320
	– W-MF SE 512 S22 230V	605 321
5.08	Solenoid coil	
	– W-MF 507 No. 032P 220-240V	605 255
	– W-MF 512 No. 042P 220-240V	605 257
5.09	Breather plug with filter element $G^1/_8$	605 302
5.10	Pressure switch GW 50 A5/1 5 … 50 mbar	691 378
	with screws and O ring	
5.11	O ring 10.5 x 2.25	445 512
5.12	Filter insert with seal	
	– W-MF 507	605 253
	– W-MF 512	605 254
5.13	Flange W-MF	
	– 507 Rp¾	605 227
	– 507 Rp1	605 233
	– 512 Rp1	605 228
5.14	Double nipple	
	– R¾ x 50 with Loctite	139 000 26 727
	– R1 x 50 with Loctite	139 000 26 737
5.15	Isolating valve with TAE	
	– 998 N G¾ CE-TAS for Gas PN1	454 596
	– 998 N G1 CE-TAS for Gas PN 1	454 597
	Isolating valve without TAE	
	– 984 D Rp¾ PN 40/MOP5	454 660
	– 984 D Rp1 PN 40/MOP5	454 661

14 Notes

A

Actuator ... 60
Air damper ... 11, 40, 60, 61, 63
Air number ... 49
Air pressure ... 50
Air pressure switch ... 11, 47
Air regulator ... 63
Ambient conditions ... 16
Ammeter ... 32
Angle drive ... 61
Aperture ... 21, 22, 24
Appliance category ... 77
Approval data ... 16

B

Bar ... 76
Basic setting ... 56
Boiler room ... 7
Booming ... 73
Breaks in operation ... 51
Breather plug ... 65
Burner motor ... 13, 59

C

Calorific value ... 38
Capacity ... 18
Capacity graph ... 18
CO content ... 49
Coil ... 64
Combustion air ... 7
Combustion chamber pressure ... 18
Combustion control ... 49
Combustion head ... 18
Combustion head extension ... 21
Combustion heat rating ... 18, 40
Combustion limit ... 49
Combustion manager ... 13, 30
Commissioning ... 31
Condensate ... 8
Connection pressure ... 25, 33, 38
Consumption ... 16
Conversion factor ... 50
Conversion table ... 76
Current measuring device ... 32

D

Design lifespan ... 7, 52
Diffuser ... 11, 40, 41
Dimensions ... 19
Display ... 30
Disposal ... 8
Double gas valve ... 12, 25
Drilling diagram ... 21
Ducted air intake ... 7, 18

E

Electrical connection ... 29
Electrical data ... 16
Electrode ... 57
Electrostatic discharge ... 8
Emission ... 17
Emission class ... 17
Error code ... 69
Error codes ... 70, 73
Errors ... 70
ESD protection measures ... 8
Excess air ... 49

F

Fabrication number ... 10
Fan motor ... 59
Fan pressure ... 32
Fan wheel ... 11, 58
Fault ... 68, 73
Fault history ... 69
Faults ... 73
Filter ... 12, 66
Filter insert ... 66
Flame signal ... 13, 32
Flame tube ... 21
Flashing codes ... 70, 73
Flue gas losses ... 49
Flue gas measurement ... 49
Flue gas temperature ... 49
Fuel ... 16
Fuel release ... 14
Full load ... 43
Fuse ... 67
Fusing ... 16

G

Gas butterfly valve ... 12
Gas connection pressure ... 25, 33
Gas family ... 77
Gas filter ... 12, 66
Gas isolating valve ... 12, 20
Gas pressure switch ... 12, 27
Gas setting pressure ... 38
Gas supply ... 25
Gas temperature ... 50
Gas throughput ... 50
Gas valve train ... 20, 22, 25, 26, 38
Guarantee ... 6

H

Heat exchanger ... 21
High gas pressure switch ... 13, 46
Hours counter ... 75
Housing cover ... 58
Humidity ... 16

I

Ignition ... 14
Ignition electrode ... 57
Ignition unit ... 13
Illuminated push button ... 30, 68, 69
Indicating bolt ... 41
Initialisation time ... 15

15 Key word index

Installation ... 21, 22
Installation elevation ... 16, 18
Installation location ... 21
Installation position ... 25
Intake housing ... 63
Ionisation current ... 32
Ionisation electrode ... 13, 57
Isolating valve ... 12, 20

L

Liability ... 6
Lifespan ... 7, 52
Limit switch ... 41
Lockout ... 68, 70, 73
Low gas pressure switch/valve proving gas pressure switch ... 12, 46

M

Mains voltage ... 16
Maintenance position ... 58
mbar ... 76
Measuring device ... 32
Mixing head ... 11, 40, 55, 56
Mixing pressure ... 32
Monitoring current ... 32
Motor ... 13, 59
Multifunction assembly ... 12

N

Name plate ... 10
Noise ... 73
Nominal diameter ... 38

O

Operating hours counter ... 75
Operating problems ... 73
Operating volume ... 50

P

Pa ... 76
Partial load ... 44
Pascal ... 76
Personal protective equipment ... 7
Plug assignment ... 74
Post-purge ... 14
Post-purge time ... 15
PPE ... 7
Pre-ignition time ... 15
Pre-purge ... 14
Pre-purge time ... 15
Pressure measuring device ... 32
Pressure regulator ... 12, 25
Pressure switch ... 11, 47
Pressure switches ... 41
Program sequence ... 14
Protective equipment ... 7
Pulsating ... 73

R

Refractory ... 21
Remote reset ... 29
Reset ... 69
Reset button ... 30
Residence time ... 15

S

Safety measures ... 7
Safety time ... 14, 15
Sequence diagram ... 14
Serial number ... 10
Service ... 52
Service contract ... 52
Service interval ... 52
Service plan ... 54
Service position ... 58
Setting diagram ... 40
Setting dimensions ... 56
Setting pressure ... 38
Setting screw ... 56
Shutdown ... 51
Shutdown time ... 51
Signal lamp ... 30
Smell of gas ... 7
Solenoid coil ... 64
Sound ... 17
Sound power level ... 17
Sound power levels ... 17
Sound pressure level ... 17
Soundness test ... 34
Spares ... 83
Stability problems ... 73
Standard volume ... 50
Standards ... 16
Storage ... 16

T

Temperature ... 16
Test phase ... 15
Test points ... 36
Test pressure ... 34
Transport ... 16
Troubleshooting ... 73
Type key ... 9
Type of gas ... 16, 77

U

Unit ... 76
Unit fuse ... 67
Unit of pressure ... 76

V

Valve proving ... 12, 46
Valve train ... 26
Voltage supply ... 16

W

Weight 20
Wiring diagram 74

–weishaupt–

Max Weishaupt GmbH · 88475 Schwendi

Weishaupt close by? Addresses, telephone numbers etc. can be found at www.weishaupt.de

We reserve the right to make changes. All rights reserved.

The complete program: Reliable technology and prompt, professional service



W Burners **up to 570 kW**

The compact burners, proven millions of times over, are economical and reliable. Available as gas, oil and dual fuel burners for domestic and commercial applications.
The purflam® burner version with special mixing head gives almost soot-free combustion of oil with greatly reduced NOx emissions.




monarch® WM Burners and Industrial Burners **up to 11,700 kW**

These legendary industrial burners are durable and versatile.
Numerous variations of oil, gas and dual fuel burners meet a wide range of applications and capacity requirements.



WKmono 80 Burners **up to 17,000 kW**

The WKmono 80 burners are the most powerful monoblock burners from Weishaupt. They are available as oil, gas or dual fuel burners and are designed for tough industrial application.



WK Burners **up to 32,000 kW**

These industrial burners of modular construction are adaptable, robust and powerful.
Even on the toughest industrial applications these oil, gas and dual fuel burners operate reliably.




MCR Technology / Building Automation from Neuberger

From control panels to complete building management systems - at Weishaupt you can find the entire spectrum of modern control technology. Future orientated, economical and flexible.



Service

Weishaupt customers can be assured that specialist knowledge and tools are available whenever they are needed. Our service engineers are fully qualified and have extensive product knowledge, be it for burners, heat pumps, condensing boilers or solar collectors.




Wall-hung condensing boilers for gas **up to 240 kW**

The wall-hung condensing boilers WTC-GW have been developed to meet the highest demands in ease of operation and efficiency. Modulating operation means these units operate quietly and economically.



Floor-standing condensing boilers for oil and gas **up to 1,200 kW**

The floor-standing condensing boilers WTC-GB (up to 300 kW) and WTC-OB (up to 45 kW) are efficient, low in pollutants and versatile in use.
Even the largest capacities can be covered by cascading up to four gas condensing boilers.



Solar systems

The stylish flat-plate collectors are the ideal complement for any Weishaupt heating system. They are suitable for solar water heating and for combined heating support. With versions for on-roof, in-roof and flat roof installations, solar energy can be utilised on almost any roof.



Water heaters/Energy storage

The diverse program of potable water and energy storage for various heat sources includes storage volumes of 70 to 3,000 litres. In order to minimize storage losses, potable water cylinders from 140 to 500 litres are available with highly efficient insulation using vacuum insulation panels.



Heat pumps **up to 180 kW**

The heat pump range offers solutions for the utilisation of heat from the air, the soil or ground water.
Some systems are also suitable for cooling buildings.



Geothermal probe drilling

With its daughter company, BauGrund Süd, Weishaupt also offers geothermal probe and well drilling. With the experience of more than 10,000 systems and more than 2 million meters of drilling, BauGrund Süd offers a comprehensive service program.